



# ORIGINAL LENSPEN

## REINIGUNGSSTIFF CLEANING PEN

Speziell für Glaslinsen

### GEBRAUCHSANWEISUNG

1. Entfernen Sie Staubpartikel mit dem ausfahrbaren **Pinsel**.
2. Entfernen Sie die Stiftkappe und wischen Sie die Oberfläche mit sanften, kreisförmigen Bewegungen mit der flexiblen **Reinigungsspitze** ab. Bei hartnäckigem Schmutz auf der Linse, hauchen Sie die Oberfläche an und wiederholen Sie den Vorgang.
3. Abschließend schrauben Sie die Kappe mit einer **halben Drehung** wieder auf den Stift. **Durch die Drehung wird die Reinigungsspitze aufgefrischt.**

#### WICHTIG:

Nicht auf nassen Oberflächen anwenden.

Especially for glass lenses

### INSTRUCTIONS FOR USE

1. Remove dust particles with the extendable **brush**.
2. Remove the cap and wipe the surface with gentle circular motions using the unique flexible **cleaning tip**. For persistent dirt on the lens, breathe on the surface and repeat the process.
3. Finally, screw the cap back onto the pen with a **half twist**. **Twisting the cap replenishes the unique cleaning pad.**

#### IMPORTANT:

Do not use on wet surfaces.

